

SCULPT NOUVEAU Patinas and Metal Finishes

Light Green Patina Techniques



Water Wash Technique:

1. Sandblast metal or clean with IMS Metal Cleaner.
2. Spray on Light Green Patina and allow to react for 1-2 hours until pea-green in color.
3. Rinse metal with hot water for one minute. The patina will turn brown, green, and orange.
4. Allow the patina to dry for 2-3 hours, then seal with two coats of Permalac.



Steel Wool Technique:

1. Sandblast metal or clean with IMS Metal Cleaner.
2. Spray on Light Green Patina and allow to react for 2-3 hours.
3. Reapply the Light Green Patina.
4. Rub wet patina surface with 0000 steel wool.
5. Allow to react for 2-3 hours. The rubbed areas will turn brown, yellow, and orange.
6. Seal with two coats of Permalac.