

Metal Rub Instructions

1. Clean the surface. If you are working on metal, lightly sandblast.
2. Rub on the metal paste - not much is needed.
3. Let cure for 12 hours.
4. Buff with cloth.
5. Spray with deft satin.
6. Now any of the colored waxes, universal patinas, or dye oxides may be applied.
7. If you use the wax, buff in 1 - 3 hours.
8. If you use the universal or dye oxide patinas, you may want to seal with wax or lacquer.