

SCULPT NOUVEAU Patinas and Metal Finishes

Patina Techniques for Resin/Cold Casting

There are many ways to easily achieve a successful patina finish on cold cast resin. First, metal powder may be added to the resin prior to pouring. Once cast, the piece should be sandblasted with fine grain sand to both preserve detail and prepare the surface for a patina. Secondly, the Metal Coatings may be sprayed directly onto cast resin. Finally, the Metal Coating Type C may be used as a gel-coat during the casting process. Before applying a patina to any dry Metal Coating, the surface should first be roughened with a scotchbrite pad.



Bronze cold cast resin with Liver of Sulfer, Dark Brown, and Tiffany Green patinas (left to right).



Copper cold cast resin with Mahogany, Light Green, and Vista Blue patinas (left to right).